



Mazworx SR20VE Main Stud Kit 11003

- This kit does not fit blocks with girdles
- Clean parts with brake cleaner before use
- Apply a small amount of motor oil on bottom threads
- Install stud into block till it bottoms out. Hand tight only.
- Install main caps
- Apply ARP lube on fine threads of studs
- Place washers onto studs
- Apply ARP lube on bottom of nuts
- Thread nut on stud
- Torque nuts in factory sequence to the following specs:
 1. 45 ft-lbs
 2. 65 ft-lbs

Package contents

- Main studs 10pcs
- Washers 10pcs
- Nuts 10pcs
- ARP Lube 1pc